



BEST PRACTICE GUIDE

HOW DO I GET THE BEST OUT OF MY ANALYSER?

- ✓ Ensure you charge your analyser fully when the battery is flat – switch off your analyser before you start charging
- ✓ Perform regular user zero calibrations, this will keep your analysers at optimum accuracy and will not affect the factory calibration

Tip! Store your analyser in a dry and warm place when not in use

- ✓ If the analyser gets wet, remove it from the soft carry case to dry out
- ✓ Check and replace the filters regularly and carry spares for when you're out on site

Tip! Although robust, your analyser is still a scientific piece of equipment and should be treated with care

- ✓ Regular air purges between readings and at the end of your monitoring will prolong the life of the analyser's electrochemical cells; we recommend a minimum of 30 seconds
- ✓ If you are using a G100 / G110 / G150, don't worry if you have to adjust the flow fail settings, this is merely so that it is adjusted appropriately to its new environment.

Tip! If you require any further assistance, try our support videos on our website



www.qedenv.com



+44(0) 333 800 0088



technical@qedenv.co.uk



www.youtube.com/GeotechTV